



818 896 4006  
indiedolly@gmail.com  
www.indiedolly.com

*Movement for your motion picture.*

### **Mounting IDS Slider track onto a 100mm bowl tripod.**



In order to mount a section of IDS Slider "plus" track onto a tripod, you need a tripod with a 100mm bowl.

Place the support unit onto the tripod so that the machined edge of the disc sleeves into the rim of the 100mm bowl.

Then use the long tightening bolt to securely fasten the support unit to the tripod.

Position the track onto the support unit and secure it with the 4 bolts.

In case that you have purchased a 3rd support unit you can also mount a support where the track sections meet.

The support unit will then function as a connector of the track sections as well as support for the track.



You can rotate the track section in order to tighten the bolt on the bottom even more.

(Btw: This may make the bolt too tight to be loosened by hand, simply rotate the track again in the other direction in order to loosen the bolt.)